

AIRFLUSH®

Maintenance Instructions

Daily

The bowls should be wiped once a day with mild detergent and warm water. Alternatively our biodegradable urinal cleaner can be used.

Weekly

Once a week, each urinal should be flushed with about two litres of warm water and a little detergent (E.G. washing up liquid) to keep pipes clear.

Monthly

The trap at the lower end of the branch discharge pipe should be cleaned out regularly.

In high-usage installations this might be monthly, but where usage is lower this might be every six months.

The trap has a removable cleaning eye to allow sludge to be drained into a shallow container.

The installation should be odour free. If odour is coming from the urinal (as opposed to unclean surroundings) check that the fan is running.

For UK spares and support contact Cubicle Centre

T (01924) 457600

E sales@washroomcubicles.co.uk

Unit 33 Caldervale Business Park | Ravensthorpe | West Yorkshire | WF13 3JL