



Maintenance Instructions

Cubicle Panels

Remove general stains and marks with a non-aggressive bathroom or kitchen surface cleaning solution on a damp cloth.

Do not use excessive amounts of water or solution and avoid scrubbing or using anything with sharp edges in contact with the panels.

Quarterly

Check the cubicle fittings. Spares can be ordered from sales@washroomcubicles.co.uk

Annually

Check all panels and edgings for integrity, particularly if they have any reason become exposed to water or damp atmosphere.

Cubicle Hardware

Cleaning

Fittings should be cleaned frequently. Use a mild anti-bacterial detergent and damp cloth for anodised fittings. For powder-coated fittings use a polish and non-abrasive cloth. Do not use corrosive chemicals.

Lubrication

Lightly lubricate the indicator bolt mechanism every six months to ensure continuity of movement. Light lubrication of the hinges is also required to avoid the door sticking and deterioration of the riser.

Periodic Inspection

Periodically inspect all fixings, adjust and secure as and when needed. Ensure correct Allen keys, screw drivers and drill bits are used. Do not over tighten fixings.

Safety mechanisms must also be inspected frequently in case of vandalism. If vandalism occurs the part should be replaced as soon as possible to avoid any accidents.

For spares and support contact Cubicle Centre

T (01924) 457600

E sales@washroomcubicles.co.uk

Unit 33 Caldervale Business Park | Ravensthorpe | West Yorkshire | WF13 3JL